

Key Notes:

- Ensure that your robot is turned off and that the power switch on the bottom of the foot is in the off position or that the battery has been removed.
- Allow sufficient time for the cleaning product to dry before powering on your robot.
- Please be extremely gentle around the lips, eyebrows or other painted areas of the face, the adhesive can pull off some of these decorations if used too aggressively.
- For residue and If there is any residue like food or build up of dirt, you can spot clean the robot with a slightly damp cloth.
- A mild detergent can also be used if needed, however you may want to spot check



To disinfect or sanitize your robot use a Lysol brand wipe (do not use a Clorox or other bleach wipe as this can affect the pigment of the skin or plastics).

- **Robot Body & Hair:**
 - Use a dry microfiber cloth for dust on any of the hard plastics, back panel of connectors (i.e. power jack, USB, etc.).
- **Robot Face**
 - Lint and dust on the robot's face can be removed by using the adhesive side of a standard post it note.
 - Gently apply the adhesive side to the robots skin over areas where lint and dust have collected.
 - Gently peel the post it note off the robot and the lint and dust will stick to the post it note.
- **Chest Screen:**
 - The screen can be cleaned with a microfiber cloth, or other similar item that you would use to clean eyeglasses or a cell phone screen.